

RUOLO / Player	STRUMENTO/ Instrument	INPUT	MICROFONO SUGGERITO / SUGGEST MICROPHONE	AUX	MONITOR	
VOCE 1 / VOX 1	Microphone & stand	1	Shure SM58	1	Monitor	
CHITARRA ACUSTICA / ACUSTIC GUITAR	Kemper (Pedalboard)	2	XLR/L Female	6	Monitor	
		3	XLR/R Female			
CHITARRA ELETTRICA / ELECTRIC GUITAR ----- VOCE 2 / VOX 2 ----- CHITARRA CLASSICA / CLASSIC GUITAR	Helix(Pedalboard) + Remote o AMPLI	4/5	XLR Female	2	Monitor	
	Microphone & stand	6	Shure SM58			
BASSO / BASS	Amp + Pedalboard	7	Line from Amp true DI or Microphone in front of Amp	3	Monitor	
TASTIERE / KEYBOARDS ----- FLUTE ----- Laptop	Stage Piano	8/9	D.I. (Stereo)	4	Monitor	
	Hammond Organo	10/11	D.I. (Stereo)			
	Moog Synth	12	D.I. (Mono)			
	PC		HDMI			
BATTERIA / DRUM ----- VIBRAFONO / VIBROPHONE	Kick	13	AKG D112 (or equivalent)	5	Monitor	
	Snare top	14	Shure SM57 (or equivalent)			
	Snare Bottom	15	Shure SM57 (or equivalent)			
	Tom 1	16	Sennheiser MD421 (or equivalent)			
	Tom 2	17	Sennheiser MD421 (or equivalent)			
	Floor Tom 1	18	Sennheiser MD421 (or equivalent)			
	Floor Tom 2	19	Sennheiser MD421 (or equivalent)			
	HiHat 14"	20/21	2 x AKG C 451B (or equivalent)			
	Crash 14"					
	Crash 16"					
	Clap 14"					
	Crash 18"					
	Ride 22"					
	China 16"					
Vibraphone	22/23	2 x AKG C 451B (or equivalent)				

**PRESE DI
CORREN
TE /
POWER
SUPPLY**

3

3

4

3

5

2